



WFCO Product List

WF-8500 Series Power Center 40 and 60 Amps DC	
WF-8540-S	30 Amp AC service, Main and 9 branch AC circuits, 13 DC branch circuits, 40 Amps, Screw Terminals
WF-8540-Q	30 Amp AC service, Main and 9 branch AC circuits, 13 DC branch circuits, 40 Amps, QC Terminals
WF-8540-W	30 Amp AC service, Main and 9 branch AC circuits, 13 DC branch circuits, 40 Amps, Pig Tail Wires
WF-8560-S	30 Amp AC service, Main and 9 branch AC circuits, 13 DC branch circuits, 60 Amps, Screw Terminals
WF-8560-Q	30 Amp AC service, Main and 9 branch AC circuits, 13 DC branch circuits, 60 Amps, QC Terminals
WF-8560-W	30 Amp AC service, Main and 9 branch AC circuits, 13 DC branch circuits, 60 Amps, Pig Tail Wires

WF-8700 Series Power Center 12 to 40 Amps DC	
WF-8712-P	30 Amp AC service, Main and 3 branch AC circuits, 4 DC branch circuits, 12 Amps
WF-8712-PB	30 Amp AC service, Main and 3 branch AC circuits, 4 DC branch circuits, 12 Amps - Black
WF-8725-P	30 Amp AC service, Main and 3 branch AC circuits, 4 DC branch circuits, 25 Amps
WF-8725-PB	30 Amp AC service, Main and 3 branch AC circuits, 4 DC branch circuits, 25 Amps - Black
WF-8735-P	30 Amp AC service, Main and 5 branch AC circuits, 6 DC branch circuits, 35 Amps
WF-8735-PB	30 Amp AC service, Main and 5 branch AC circuits, 6 DC branch circuits, 35 Amps - Black
WF-8740-P	30 Amp AC service, Main and 5 branch AC circuits, 6 DC branch circuits, 40 Amps
WF-8740-PB	30 Amp AC service, Main and 5 branch AC circuits, 6 DC branch circuits, 40 Amps - Black

WF-8935 Series Power Center - 35 Amps DC	
WF-8935PEC	30 Amp AC service, Main and 5 branch AC circuits, 11 DC branch circuits
WF-8935PEC-B	30 Amp AC service, Main and 5 branch AC circuits, 11 DC branch circuits - Black
WF-8935-MBA	Replacement Converter - Main Board Assembly

WF-8945 Series Power Center - 45 Amps DC	
WF-8945PEC	30 Amp AC service, Main and 5 branch AC circuits, 11 DC branch circuits
WF-8945PEC-B	30 Amp AC service, Main and 5 branch AC circuits, 11 DC branch circuits - Black
WF-8945PEC-B/T30	30 Amp AC service, Main and 5 branch AC circuits, 11 DC branch circuits with T-30 - Black
WF-8945-MBA	Replacement Converter - Main Board Assembly

WF-8955 Series Power Center - 55 Amps DC	
WF-8955PEC	30 Amp AC service, Main and 5 branch AC circuits, 11 DC branch circuits. New Generation
WF-8955PEC-B	30 Amp AC service, Main and 5 branch AC circuits, 11 DC branch circuits. New Generation - Black
WF-8955PEC-B/T30	30 Amp AC service, Main and 5 branch AC circuits, 11 DC branch circuits. New Gen. - Black with T-30
WF-8955PEC/T30	30 Amp AC service, Main and 5 branch AC circuits, 11 DC branch circuits. New Gen. with T-30
WF-8955-MBA	Replacement Converter - Main Board Assembly
WF-8955PEC-MBA	Replacement Converter - Main Board Assembly - New Generation

WF-8965 Series Power Center - 65 Amps DC	
WF-8965AN-P	30 Amp AC service, Main and 5 branch AC circuits, 11 DC branch circuits
WF-8965AN-PB	30 Amp AC service, Main and 5 branch AC circuits, 11 DC branch circuits - Black
WF-8965AN/T30	30 Amp AC service, Main and 5 branch AC circuits, 11 DC branch circuits with T-30
WF-8965ANPB/T30	30 Amp AC service, Main and 5 branch AC circuits, 11 DC branch circuits - Black with T-30
WF-8965-MBA	Replacement Converter - Main Board Assembly

WF-8975 Series Power Center - 75 Amps DC	
WF-8975AN-P	30 Amp AC service, Main and 5 branch AC circuits, 11 DC branch circuits
WF-8975AN-PB	30 Amp AC service, Main and 5 branch AC circuits, 11 DC branch circuits - Black
WF-8975-MBA	Replacement Converter - Main Board Assembly

WF-9960 Series Power Center - 60 Amps DC	
WF-9960	50 Amp AC service, Main and 12 branch AC circuits, 18 DC branch circuits

WF-9990 Series Power Center - 90 Amps DC	
WF-9990	50 Amp AC service, Main and 12 branch AC circuits, 18 DC branch circuits

Transfer Switches	
T-30	30 Amps Automatic Power Transfer - Shore to Generator
T-57P	50 Amps Automatic Power Transfer - Shore to Generator

Universal Replacement Kits for Non-WFCO Power Centers	
WF-8945-REP	Converter/Charger 45 Amps DC Output, includes 11 branch circuit fuses, using WF-9845
WF-8955-REP	Converter/Charger 55 Amps DC Output, includes 11 branch circuit fuses, using WF-9855

WF-6800 Series Deckmount Converter/Charger – 80 to 100 Amps DC	
WF-68100	100 Amps DC Output with Power Factor Correction, reverse polarity fuses (15 Amps AC Power Cord)

WF-9800 Series Deckmount Converter/Charger – 35 to 75 Amps DC	
WF-9835	35 Amps DC Output, reverse polarity fuses (15 Amps AC Power Cord)
WF-9845	45 Amps DC Output, reverse polarity fuses (15 Amps AC Power Cord)
WF-9855	55 Amps DC Output, reverse polarity fuses (15 Amps AC Power Cord)
WF-9865	65 Amps DC Output, reverse polarity fuses (20 Amps AC Power Cord)
WF-9875	75 Amps DC Output, reverse polarity fuses (20 Amps AC Power Cord)

220VAC Models (used in Europe, Australia or wherever 220VAC is available)	
WF-8725E	Power Center for 220V AC service, Main and 3 branch circuits, 25 Amps DC Output with 4 circuits
WF-8725EB	Power Center for 220V AC service, Main and 3 branch circuits, 25 Amps DC Output with 4 circuits - Black
WF-8735E	Power Center for 220V AC service, Main and 3 branch circuits, 35 Amps DC Output with 4 circuits
WF-8735EB	Power Center for 220V AC service, Main and 3 branch circuits, 35 Amps DC Output with 4 circuits - Black
WF-8955E	Power Center for 220V AC service, Main and 5 branch circuits, 55 Amps DC Output with 11 circuits
WF-8955EB	Power Center for 220V AC service, Main and 5 branch circuits, 55 Amps DC Output with 11 circuits - Black
WF-8855E	Converter/Charger Deckmount for 220V AC, 55 Amps DC Output (15 Amps power cord)

WF-8930/50 Series Distribution Panel	
WF-8930/50NP	30 Amp or 50 Amp AC service, Main and 12 branch AC circuits, 15 DC circuits
WF-8930/50NPB	30 Amp or 50 Amp AC service, Main and 12 branch AC circuits, 15 DC circuits - Black
WF-8930/50NP-30	30 Amp AC service, Main and 5 branch AC circuits, 15 DC circuits
WF-8930/50NPB-30	30 Amp AC service, Main and 5 branch AC circuits, 15 DC circuits - Black

WF-5100 Series Pure Sine Wave Power Inverter	
WF-5110HP	1,000 Watt provided with hard-wired installation

Door and Door Assembly References

	WF-8930/50 Series Brown		WF-8930/50 Series Black	
	Door Only	Door Assembly	Door Only	Door Assembly
With Window				
Paddle fin on the right side	WF-8930/50NNP-DO-P	WF-8930/50NNP-DA (9" x 13")	WF-8930/50NNPB-DO-P	WF-8930/50NNPB-DA
Side-hinged flaps				
Bottom-hinged pin	WF-8930/50NNP-DO-B		WF-8930/50NNPB-DO-B	
Extended Door				WF-8930/50NNPB-50-PDA
No Window				
Three tabs on the bottom		WF-8930/50-PDA (9" x 14-5/8")		WF-8930/50-PDAB

	WF-8900 Series Brown		WF-8900 Series Black	
	Door Only	Door Assembly	Door Only	Door Assembly
*xx = Model Amperage				
New PEC models	WF-8910PEC-DO	WF-89xxPEC-DA	WF-8910PEC-DOB	WF-89xxPEC-B-DA
Old 8735/45/55 ANP Models	WF-8910-PDO	WF-89xx-PDA	WF-8910-PDOB	WF-89xx-PDAB
Old 8765/75 ANP Models	WF-8965/75-PDO	WF-89xx-PDA	WF-8965/75-PDOB	WF-89xx-PDAB

	WF-8700 Series Brown		WF-8700 Series Black	
	Door Only	Door Assembly	Door Only	Door Assembly
*xx = Model Amperage				
ANP models WF8712/25	WF-8700-PDO	WF-87xx-PDA	WF-8700-PDOB	WF-87xx-PB-DA
ANP models WF8735/40	WF-8735/40-PDO	WF-87xx-PDA	WF-8735/40-PB-DO	WF-87xx-PB-DA

Fuse Boards/Panels		Door Latches
Component	Part Number	
WF-89xx ANP, PEC & E	8935/45/55-PCB	WF-87/8900-DL
WF-8965 & 8975 Models	8965/75AN-PCB	
WF-8930/50NP	8930/50N-PCB	
WF-8955-REP	NO PART NUMBER	

* Note: For model numbers listed with an "xx" replace with your converter model amperage, i.e. WF-8955: xx=55.